

Tech Brief

Part Number: 9010205



Figure 1



Figure 2



Figure 3



Figure 4

1980 thru 1990 Ford Broncos Full Size and F-Series Pickups With Air Conditioning

1. Swivel the pipes into the configuration shown in Figure 1 so that it matches the original heater.
2. Insert the pipes into the pipe holes located in the plastic case.
3. Push the bottom tank of the heater into the bottom of the heater cavity as shown in Figure 2.
4. Push the top tank and pipes into the case as shown in Figure 4.